

AVIOELECTRONICS REPAIR CAPABILITY LIST 25/05/2017

DESCRIPTION	MODEL/TYPE	P/N	MANUFACTERER OEM
INDICATORE R.M.I.	C-6E	1784460-525	SPERRY
CARTRIDGE TAPE DRIVE	650	QTNX TM 1001	QANTEX
POWER SUPPLY		56PS1001-1	AERITALIA
CARD A5 CANALE 3		16CT1006-1	AERITALIA
CARD A6 CANALE 5/6		16CT1008-1	AERITALIA
CARD A8 EVENT CHANNEL 4		16CT1010-1	AERITALIA
CARD A8 CONVERSIONE SINCRO		16CT1007-1	AERITALIA
CARD A6		16CT1011-1	AERITALIA
POWER CONTROL PANEL		55PS1001-1	AERITALIA
POWER CONTROL PANEL		54PS1001-1	AERITALIA
FLIGHT ISPECTION COMPUTER		2-00063-200-001	ARMA
CONTROL DISPLAY UNIT		2-00064-200-003	ARMA
MSGU		09CP1001-1	AERITALIA
SIGNAL ANALYZER UNIT	SAU-7000	7124-0140-1	SIERRA/KING
SIGNAL ANALYZER UNIT	SAU-7000	7124-0140-2	SIERRA/KING
SIGNAL ANALYZER UNIT	SAU-7000	7124-0140-4	SIERRA/KING
RICETRASMETTITORE D.M.E.	SRU-7000B	7808-5000-1	SIERRA/KING
TACAN SYSTEM	SANS-7000A		SIERRA/KING
ANALOG BEARING UNIT	SBU-7000A	7124-3000-4	SIERRA/KING
SCHEDA RADIOMISURE VOR 51RV-4B		648-4778	COLLINS
RICEVITORE VOR/ ILS	51RV-4B-FIS	648-4774-004	COLLINS
AUTOMATIC OMNIBIRING SELECTOR		89164S-8	CONRAC
INDICATORE R.M.I.	RH-4XX	4002963-405	SPERRY
DATA TRANSFER MODULE	3265A2	164191-01-02	SMITHS INDUSTRIES
DIGITAL ALTIMETER INDICATOR		520-16100-8	IDC
COMPASS COUPLER		2591201-901	SPERRY
COMPASS CONTROLLER		2591202-901	SPERRY
ENCODING ALTIMETER UNIT	518-28007	518-2807-208	IDC
SCATOLA INTERCONNESSIONE	JZ07	07JZ1001-7	AERITALIA
SCATOLA INTERCONNESSIONE	JZ07	07JZ1001-6	AERITALIA
SCATOLA INTERCONNESSIONE	JZ07	07JZ1001-2	AERITALIA
SCATOLA INTERCONNESSIONE	JZ07	07JZ1001-3	AERITALIA

SCATOLA INTERCONNESSIONE	JZ07	07JZ1001-4	AERITALIA
SCATOLA INTERCONNESSIONE	JZ07	07JZ1001-1	AERITALIA
ELECTRONIC CONTROL AMPLIFIER	MA-4A	618319-3	SPERRY
ACCOPIATORE MODI	161E-2	772-5132-001	COLLINS
ACCOPIATORE MODI	161E-2	772-5132-001	COLLINS
QUADRETTO COMANDO AUTOPILOTA	614E-4	522-3551-001/2/3/4	COLLINS
ACCOPIATORE TRIM	161A-1B	522-4649-001/4/7/11/12/15	COLLINS
SELETTORE MODI DIRETTORE DI VOLO	614E-23P	622-2248-001	COLLINS
INDICATORE FDI	329B-8G	777-1224-001/2/3/4	COLLINS
CALCOLATORE DI VOLO	562A-5M	722-5130-001/2/3/4/5/6/7/8/9/10/11/12/13/14/15/17/19/21	COLLINS
ACCOPIATORE DATI ARIA	161F-1	522-4700-XXX	COLLINS
INDICATORE DI ROTTA HSI	331A-8H	777-1026-001/2/3/4/5/6	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20	772-5232-001/2/3/4	COLLINS
GIROSCOPIO VERTICALE	332D-11	522-3985-001	COLLINS
GIROSCOPIO VERTICALE	332D-11A	792-6694-001/002	COLLINS
GIROSCOPIO VERTICALE	332D-11V	622-4424-001	COLLINS
GIROSCOPIO VERTICALE	332D-11T	622-4565-001	COLLINS
GIROSCOPIO	332G-2	229-0236-000	COLLINS
GIROSCOPIO	332G-2	229-0310-010	COLLINS
RICEVITORE MARKER BCN	51Z-4	522-2996-011	COLLINS
ELABORATORE DATI ARIA	590A-5	522-4701-001/002	COLLINS
REMOTE HEADING AND COURSE SELECTOR	614E-22	772-5403-001/2/3/4	COLLINS
COMPARATORE ALLARMI	54W-1C	522-3948-001	COLLINS
SYNCROPHASER		752400	HAMILTON STD
SENSORE ACCELEROMETRO	345C-2A	522-4329-001	COLLINS
SERVO MOTORE	334C-3C	772-5472-001	COLLINS
SYNCR0 ADAPTER UNIT		A4608000002	KOLLSMAN
QUADRETTO ADF	UC1A	144-0201/09	MARCONI
SENSORE VIROSBANDOMETRO	345A-7	772-5140-001	COLLINS
SENSORE VIROSBANDOMETRO	345A-7A	777-1034-001	COLLINS
SENSORE VIROSBANDOMETRO	345A-7B	622-0181-001	COLLINS
INDICATORE RADAR ALTIMETRO	ID03	03ID1001-1 (JG206D1)	AERITALIA
WHISHELD TEMPERATURE CONTROL		SYLZ50295-1	BARBER e COLMAN
QUADRETTO ALLARMI COMPARATORE	914G-2	522-3919-002	COLLINS
SERVO AMPLIFICATORE		1783867-1	SPERRY
SCATOLA INTERCONNESSIONE	JZ09	09JZ1001-5/6	AERITALIA
AMPLIFICATORE STRUMENTI	344C-1G	522-3866-001/2	COLLINS
SCATOLA INTERCONNESSIONE	JZ09	09JZ1001-1/2	AERITALIA
AUTOPILOT CONTROL ENGAGING UNIT		743-001	VARO INC.

AUTOPILOT CONTROL ENGAGING UNIT		743-001-1	VARO INC.
MONITOR TV	P4714	630971	FIAR
PRESSURE SWITCH		71035	HYDRA ELECTRIC CO
COCKPIT INTERFACE UNIT	3265A1	160094-02-01	SMITHS INDUSTRIES
RICETRASMETTITORE RADAR ALTIMETRO	MW09	09MW1001-1 (HG7105A)	AERITALIA
COMPENSATORE		656767	SPERRY
SELETTORE MODI AUTOPILOTA	614E-23R	622-0945-006/007/008/017	COLLINS
CARD A4 CANALE 1/7		16CT1009-1	AERITALIA
TRACKING LAMP		4400	LEAVESDEN
TRACKING LAMP CONTROLLER		4401	LEAVESDEN
TRACKING LAMP		100001-1	ALENIA
TRACKING LAMP CONTROLLER		100002-2	ALENIA
OBS SELECTOR		14CT1009-1	AERITALIA
FREQUENCY CONVERTER		10SB10042-1	AERITALIA
INDICATORE RADAR ALTIMETRO	ID13	JG206D4 (13ID1001-1)	HONEYWELL
TANK UNIT		FG232A2	HONEYWELL
TANK UNIT		FG200A48	HONEYWELL
TANK UNIT		FG200A47	HONEYWELL
TANK UNIT		FG200A3	HONEYWELL
SCATOLA GIUNZIONE	JZ18	18JZ1001-1	AERITALIA
THERMAL PRINTER	TP2000	2-00068-306	MILTOPE
COMPRESSOR INLET TEMP.CONTROL		620B2A	LEWIS ENG.
R.M.I. SWITCHING PANEL		14CT1005-1	AERITALIA
AUDIO SELECTOR PANEL		43CT1001-1	AERITALIA
MARKER BEACON CONTROL UNIT		14CT1006-1	AERITALIA
TEMPERATURE CONTROL AMPLIFIER		635E727G1	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G12	GENERAL ELECTRIC
ANTENNA RADAR ALTIMETRO	RS-01	01RS1001-1	AERITALIA
ANTENNA BCN	RV-10	10RV1001-2	AERITALIA
ANTENNA TACAN / D.M.E.	AT-741/A	CE673862-1	R.A. MILLER.IND
ANTENNA GLIDE SLOPE	RU06	06RU1001-1	ALENIA
FUEL QUANTITY INDICATOR		JG130A79	HONEYWELL
FUEL QUANTITY INDICATOR		JG130A92	HONEYWELL
FUEL QUANTITY INDICATOR		JG402A38	HONEYWELL
ELECTRONIC CONTROL AMPLIFIER		EG204A1	HONEYWELL
FUEL QUANTITY DUAL INDICATOR		JG310B2	HONEYWELL
ANTENNA COUPLER	CU03	03CU1001-1	AERITALIA
A/P SWITCHING UNIT		02AS1001-1	ALENIA
AIR DATA SENSOR		542BW2	ALENIA

RICETRASMETTITORE RADAR METEO	E190	M2211A/B/E	ECKO
ANTENNA RADAR METEO	E190	M2210	ECKO
INDICATORE RADAR METEO	E190	M2212A	ECKO
ANTENNA SERVO AMPLIFIER	E190	MSA2229	ECKO
BUSSOLA MAGNETICA	MS17983-1	8.135.003	KOLLSMAN
AMPLIFICATORE ALIMENTATORE	AM4606/ASN-75	2575892	SPERRY
GIROSCOPIO DIREZIONALE	CN1141/ASN-75	2586077-7	SPERRY
AMPLIFICATORE ALIMENTATORE	AM4606/ASN-75	8.072.001	AERITALIA
INDICATORE ACCELEROMETRO	G2	8.192.003	KOLLSMAN
INDICATORE ACCELEROMETRO		8.130.053	KOLLSMAN
INDICATORE ACCELEROMETRO	46054	8.192.010	KOLLSMAN
INDICATORE ACCELEROMETRO		8.029.005	KOLLSMAN
TURN SLIP INDICATOR	VS-1T	8.005.001	KOLLSMAN
TURN SLIP INDICATOR	VS-2T	8.006.001	KOLLSMAN
TAS TRASMITTER	1936-X03	8.017.000	KOLLSMAN
LOGIC CONVERTER UNIT		7-13PIN114	CHELTON
ENCODING ALTIMETER INDICATOR PIL		B45152-10-113	KOLLSMAN
ATTITUDE INDICATOR		705-7V6	SFENA
FILTRO ANTIDISTURBI	VR55	CE663645	AERITALIA
ANTENNA VHF/AM	RV-05	CE663653	AERITALIA
ANTENNA UHF	RU-02	CE663457	AERITALIA
TRASFORMER		2585434	SPERRY
ICE DETECTOR		831-0001	COOK ELECTRIC
VARIOMETRO		SLZ9504A	TELEDYNE
ANTENNA ATC	AT-740/A	62C74000	R.A. MILLER.IND
ANTENNA SELECTOR	AS103-1	01AS1001-1	AERITALIA
SCATOLA RELE'		590900	HAMILTON STD
CALCOLATORE YAW DAMPER	562C-8F	622-3167-XXX	COLLINS
RICETRASMETTITORE VHF/FM	ART 132A	145-0118/011	MARCONI
QUADRETTO VHF/FM		141-0681/01	MARCONI
INDICATORE ADI	329B-8Y	792-6357-001/002/003/005/006/007/008/009	COLLINS
AMPLIFICATORE AUTOPILOTA	562C-5	522-2900-XXX	COLLINS
AMPLIFICATORE AUTOPILOTA	562C-5	522-2900-016/057	COLLINS
LOBO SELECTOR		SA1474/A (CS598)	TRANSCO (MILLER)
ACCOPIATORE MODI	161E-2A	792-6255-002/3/4	COLLINS
CALCOLATORE DI VOLO	562A-5M5	792-6703-XXX	COLLINS
INDICATORE FLUSSOMETRO		8DJ142LBB4	GENERAL ELECTRIC
TRASMETTITORE FLUSSOMETRO		8TJ64GDP2	GENERAL ELECTRIC
AC/DC DISTRIBUTION ASSY		397240A1	AERITALIA

TV SYSTEM CONTROL UNIT		36CT1001-1	AERITALIA
VIBRATORE CRUSCOTTO		C10FA548-2	GLOBE
INVERTER STATICO		650-1-B	AUXILEC
CONTROL TEMP UNIT		548404-6-1	GARRET LTD
INDICATORE HSI	331A-9G	792-6091-001/2	COLLINS
AMPLIFICATORE INDICATORI COMBUSTIBILE		706-311	INTERTECHNIQUE
GENERATOR POWER CONTROL UNIT		GRC13D	MAGNETI MARELLI
RICEVITORE VOR/ ILS	51RV-5B	822-0761-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-4B	622-3257-XXX	COLLINS
INDICATORE QUANTITA' OSSIGENO		29316-4L-C1	BENDIX
CUFFIE	H10-76	12510G-21	DAVID CLARK
RICETRASMETTITORE RADAR ALTIMETRO	MW24	24MW1001-1	AERITALIA
RICETRASMETTITORE RADAR ALTIMETRO	MW24	24MW1001-2/2A	AERITALIA
RICETRASMETTITORE RADAR ALTIMETRO	MW24	24MW1001-3	AERITALIA
RELE DI CORRENTE		MF48000	LMF
ICS COM CONTROL PANEL	IA222	597-9050-000/001	COLLINS ITALIANA
ICS NAV CONTROL PANEL	IA223	597-9051-000/001	COLLINS ITALIANA
ICS AMPLIFIER	IA224	597-9053-000	COLLINS ITALIANA
ANGLE OF ATTACK TRASDUCER	TA-107	15978-7	TELEDYNE
FUEL QUANTITY DUAL INDICATOR		710-900	INTERTENIQUE
PRESSURE SWITCH		3501KPS3-5	SMITHS INDUSTRIES
3 WAY SOLENOID VALVE		2320A000	NORMALAIR GARRETT LTD
AMPLIFICATORE AUTOPILOTA	562C-4A	772-5131-XXX	COLLINS
FLIGHT COMPUTER	562A-5M	772-5130-XXX	COLLINS
SENSORE VIROSBANDOMETRO	345A-4B	522-3851-001	COLLINS
SENSORE VIROSBANDOMETRO	345A-4A	522-3491-001	COLLINS
CENTRAL SUPPRESION UNIT		01UV1001-1/3/4-00	GALILEO AVIONICA
IMAGE INTERFACE UNIT (I.F.U.)		8.323.005	GALILEO AVIONICA
IMAGE INTERFACE UNIT (I.F.U.)		8.323.001	GALILEO AVIONICA
BUS CONTROLLER MAIN COMPUTER		K310A076-21	GALILEO AVIONICA
VERTICAL SPEED INDICATOR		8.191.006	GALILEO AVIONICA
INTERFACE UNIT (I.F.U.)		8.325.010	GALILEO AVIONICA
SELECTOR AUTOPILOT FLIGHT DIRECT		8.338.001	GALILEO AVIONICA
SERVO BARO ALTIMETER		A4132210116	GALILEO AVIONICA
TACHOMETER INDICATOR		8DJ81CBD4	GENERAL ELECTRIC
CENTRAL MANINTENANCE PANEL		E538-08-001	PAGE AEROSPACE LTD
COLOR TV SENSOR CONTROL ADAPTER		30770-00000	
RICETRASMETTITORE VHF/AM	ART 151	145-0183/02	MARCONI
ICE DETECTOR		871FA312SP5A	ROSEMOUNT

OXIGEN PRESSURE INDICATOR		114.101 / 114P215	KRATOS
FUEL FLOW INDICATOR		124.558-1	KRATOS
ANGLE OF ATTACK TRASDUCER		SLZ9280	AEROSONIC
FUEL FLOW TRASMITTER		MAH4970	KEARSLEY AIRWAYS LTD
CALCOLATORE FLUSSOMETRO		MAE4994MOD01	KEARSLEY AIRWAYS LTD
REGOLATORE OSSIGENO		409423	ZODIAC
AIR DATA UNIT		1281AF3B1B	ROSEMOUNT
TRIM POSITION INDICATOR		114071-1	KRATOS
RELE GRAVINER		193D-03	GRAVINER
STROBE LIGTH		30-1033-1	GRIMES
STALL WARNING SYSTEM	CT07	07CT-1001-1	AERITALIA
RICETRASMETTITORE RADAR ALTIMETRO	MW17	17MW1001-2	AERITALIA
ANTENNA ADF		144-0109/01	MARCONI
CONVERTITORE DI FREQUENZA		144-0200/01	MARCONI
RICEVITORE ADF	ARG 80A	144-0108/01	MARCONI
LIQUID OXYGEN CONVERTER 10 LITER	GCU-24/A		ESSEX
INDICATORE ACCELEROMETRO		8.192.005	KOLLSMAN
CONTROL INTERCOMUNICATION	SET C2106/AIC18	289-4000	ANDREA RADIO
SELETTORE MODI DIRETTORE DI VOLO	614E-23	772-5410-001/2/3/4	COLLINS
SELETTORE MODI DIRETTORE DI VOLO	614E-23C	792-6470-001/2/3/4	COLLINS
SELETTORE MODI DIRETTORE DI VOLO	614E-23E	792-6669-001/2/3/4	COLLINS
SELETTORE MODI DIRETTORE DI VOLO	614E-23G	622-0210-001/2/3/4	COLLINS
BRAKE, DUAL DISK		A21297-118	MESSIER-HISPANO
SELETTORE MODI AUTOPILOTA	614E-20A	777-1563-001/2/3/4	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20D	777-1979-001/2/3/4	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20E	777-1980-001/2/3/4	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20G	622-0047-001/2/3/4	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20I	622-0263-001/2/3/4	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20H	622-0218/001/2/3/4	COLLINS
SERVO CONTROL		656541	SPERRY
SERVO CONTROL	0-3	658527	SPERRY
SERVO CONTROL	0-2	665928	SPERRY
TESTA DA RIPRESA	P4713	631171	FIAR
UNITA SINCRON E PILOTAGGIO	P4709	631071	FIAR
TESTA DA RIPRESA	P4713/B	631171-002	FIAR
UNITA SINCRON E PILOTAGGIO	P4709/B	631071-002	FIAR
MONITOR TV	P4715/B	631399	FIAR
ATTITUDE DIRECTOR INDICATOR		111303-4	ASTRONAUTICS
HORIZONTAL SITUATION INDICATOR		127450-5	ASTRONAUTICS

INDICATORE R.M.I.	RH-4XX	4002963-404	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-444	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-445	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-454	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-464	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-901	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-902	SPERRY
INDICATORE R.M.I.	RH-4XX	4002963-903	SPERRY
QUADRETTO COMANDO VOR/ ILS	313N-2	522-2447-XXX	COLLINS
QUADRETTO COMANDO VOR/ ILS	313N-2D	522-2447-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-4	622-3255-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-4A	622-3256-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-4C	622-3258-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-4D	622-3259-XXX	COLLINS
TRASPONDER IFF	RT-862A/APX77	1147272	AERITALIA
MDE		03EN1001-1	AERITALIA
CARTRIDGE RECORDER		CR600	MILTOPE
DIGITAL BEARING UNIT	SBU-7000D	7124-4000-X	SIERRA/KING
CONTROL PANEL D.M.E.	SPU-7000	7124-0130-X	SIERRA/KING
CONTROL PANEL TACAN	G-3849	G-3849A/B/C/D/E/F	SIERRA/KING
MONITOR TV		MCM31-GH-C60-TTL-FA	AEG
RICETRASMETTITORE VHF	SU116	4.355.260	ROHDE & SCHWARZ
CARTRIDGE TAPE DRIVE	2710	QTNX TM 1005	QANTEX
COMPARATORE	54W-1	522-2788-005	COLLINS
COMPARATORE	54W-1	522-2788-015/016	COLLINS
QUADRETTO ALLARMI COMPARATORE	914G-1	522-3918-001/2/9	COLLINS
QUADRETTO ALLARMI COMPARATORE	914G-1A	522-3918-003/4/11/12	COLLINS
QUADRETTO ALLARMI COMPARATORE	914G-2A	522-3919-009/10/11/12/13/14/15/16	COLLINS
INDICATORE TRIM	327D-1	458-1297-00	COLLINS
INDICATORE R.M.I.	C-6L	2587317-XXX	SPERRY
INDICATORE R.M.I.	C-6M	2588282-XXX	SPERRY
REMOTE HEADING AND COURSE SELECTOR	614E-22D	622-0142-002/3/4	COLLINS
CALCOLATORE YAW DAMPER	562C-8A	777-1406-XXX	COLLINS
CALCOLATORE YAW DAMPER	562C-8B	792-6345-001	COLLINS
SYNCROPHASER		585800	HAMILTON STD
SPEED BIAS SERVO ASSY		550512	HAMILTON STD
SPEED BIAS SERVO ASSY		710202	HAMILTON STD
PRESSURE SENSITIVE ALTIMETER	MA-1	D22061-01-004/010	KOLLSMAN
INDICATORE FDI	329B-8G	522-4529-001/2/4	COLLINS

INDICATORE FDI	329B-8G	772-5299-001	COLLINS
ACCOPIATORE TRIM	161A-1	522-2787-000	COLLINS
ACCOPIATORE TRIM	161A-1A	522-4517-001	COLLINS
RADIO SET CONTROL	714E-1	522-1261-00	COLLINS
RADIO SET CONTROL	714E-2	522-2213-00/49	COLLINS
RADIO SET CONTROL	714E-2A	522-2892-00/11/38	COLLINS
RADIO SET CONTROL	714E-2B	787-6377-001/2	COLLINS
RADIO SET CONTROL	714E-3	522-2457-00/38	COLLINS
RADIO SET CONTROL	714E-3B	522-3903-001/2	COLLINS
RADIO SET CONTROL	714E-3D	777-1029-001/2	COLLINS
RADIO SET CONTROL	714E-3F	787-6378-001/2	COLLINS
RADIO SET CONTROL	714E-3G	787-6557--001	COLLINS
SERVO MOTORE	334C-3	522-1225-000	COLLINS
SERVO MOTORE	334C-3A	522-1225-001	COLLINS
SERVO MOTORE	334C-3B	772-5334-001	COLLINS
SERVO MOTORE	334C-3D	777-1287-001	COLLINS
SERVO MOTORE	334C-3E	777-1757-001	COLLINS
SERVO MOTORE	334C-3F	777-1758-001	COLLINS
RICETRASMETTITORE HF	618T-1	522-1230-001/21/22/23	COLLINS
RICETRASMETTITORE HF	618T-1B	522-4828-001/2	COLLINS
RICETRASMETTITORE HF	618T-2	522-1501-000/41/43/44	COLLINS
RICETRASMETTITORE HF	618T-2B	522-4829-001/2	COLLINS
RICETRASMETTITORE HF	618T-3	522-1660-000/31/33/34	COLLINS
RICETRASMETTITORE HF	618T-3B	522-4830-001/2	COLLINS
RICETRASMETTITORE HF	618T-4	622-2586-001/2	COLLINS
RICETRASMETTITORE HF	618T-4B	622-2587-001	COLLINS
RICETRASMETTITORE HF	618T-5	622-2588-001/2	COLLINS
RICETRASMETTITORE HF	618T-5B	622-2589-001	COLLINS
RICETRASMETTITORE HF	618T-6	622-2590-001/2	COLLINS
RICETRASMETTITORE HF	618T-B	622-2590-001	COLLINS
ANTENNA COUPLER	490T-1	522-3443-001	COLLINS
ANTENNA COUPLER	490T-1A	522-3444-001	COLLINS
GIROSCOPIO	332G-2	229-0060-001	COLLINS
GIROSCOPIO	332G-2	548-9948-000	COLLINS
GIROSCOPIO	332G-2	548-9949-000	COLLINS
SENSORE VIROSBANDOMETRO	345A-4	522-1218-001	COLLINS
RICETRASMETTITORE TACAN	374D-1 (TCN-118)	622-0507-XXX	COLLINS
QUADRETTO CONTROLLO TACAN	377J-1	622-2510-XXX	COLLINS
QUADRETTO CONTROLLO TACAN	377J-2	622-2511-001/2	COLLINS

QUADRETTO CONTROLLO TACAN	913G-1	622-0748-001/2	COLLINS
QUADRETTO CONTROLLO TACAN	913G-2	622-2360-001/2	COLLINS
DIGITAL ANALOG ADAPTER	899L-1	622-1678-001/2	COLLINS
DIGITAL ANALOG ADAPTER	998J-1	622-4186-001	COLLINS
RICEVITORE VOR/ ILS	51RV-2B	522-4280-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-2B	522-4977-XXX	COLLINS
RICEVITORE VOR/ ILS	51RV-2B	777-1480-XXX	COLLINS
RICEVITORE VHF VOR	1051B-1	772-0790-001/2	COLLINS
RICEVITORE UHF GS	951A-1	757-0700-001	COLLINS
SERVO MOTORE	334C-9	622-0964-001/2/3/4	COLLINS
SERVO MOTORE	334C-9A	622-2366-001/2/3/4/7/8/10	COLLINS
SERVO MOTORE	334C-11	622-2733-001/2/3/4/7/8/10	COLLINS
TRIM SERVO	334D-6	622-0965-001/2/3/4/5/6/8/9	COLLINS
TRIM SERVO	334D-6A	622-3260-001/2	COLLINS
TRIM SERVO	334D-6B	622-5026-001/2	COLLINS
TRIM SERVO	334D-6C	622-5082-001/2	COLLINS
COMPUTER CONTROL	913K-1	622-0966-001/2	COLLINS
COMPUTER CONTROL	913K-1A	622-3202-001/3/4/5/8/9/10/13	COLLINS
GAIN PROGRAMMER	161H-1	622-1036-001	COLLINS
INDICATED AIRSPEED INDICATOR	590B-3	229-9016-010	COLLINS
ALTITUDE CONTROL	590A-6	229-9015-010	COLLINS
ALTITUDE CONTROL	590A-6A	270-0859-010	COLLINS
TURN SLIP INDICATOR	329T-1	270-2424-010/20	COLLINS
HORIZONT REFERENCE INDICATOR	329A-3	270-2426-010/50	COLLINS
HORIZONT REFERENCE INDICATOR	329A-3V	270-2426-020/60	COLLINS
HORIZONT REFERENCE INDICATOR	329A-4	270-2426-030/70	COLLINS
HORIZONT REFERENCE INDICATOR	329A-4V	270-2426-040/80	COLLINS
DIRECTIONAL GYRO INDICATOR	331P-1	270-2425-010	COLLINS
DIRECTIONAL GYRO INDICATOR	331P-1V	270-2425-020	COLLINS
FLUX DETECTOR	323A-5	270-2425-030	COLLINS
SLAVING INDICATOR	327C-3	270-2425-040	COLLINS
VHF REMOTE CONTROL	313N-4	522-2449-001/2	COLLINS
VHF REMOTE CONTROL	313N-4A	522-3613-001/2	COLLINS
VHF REMOTE CONTROL	313N-4B	522-3614-00/200/1/3/203/4/205	COLLINS
VHF REMOTE CONTROL	313N-4BA	522-3614-300	COLLINS
VHF REMOTE CONTROL	313N-4C	522-3615-001/201/2/202/3/5/205	COLLINS
VHF REMOTE CONTROL	313N-4D	522-3616-00/200/1/201/202	COLLINS
SINTETIZZATORE VHF	680T-1	772-8920-001	COLLINS
SINTETIZZATORE VHF	680T-2	797-1000-001/2	COLLINS

ANTENNA RADAR METEO	ANT-210	622-2495-001	COLLINS
ANTENNA COUPLER	490T-2	522-3445-001	COLLINS
ANTENNA COUPLER	490T-2A	522-3458-001	COLLINS
RADAR DISPLAY CONTROL PANEL	DCP-270	622-6607-001/2/3/4/5/6/7/8/9	COLLINS
RADAR DISPLAY CONTROL PANEL	DCP-300	622-6607-001	COLLINS
ANTENNA RADAR METEO	ANT-212	622-2494-001	COLLINS
ANTENNA RADAR METEO	ANT-212D	622-4020-001	COLLINS
ANTENNA RADAR METEO	ANT-310	622-2502-001	COLLINS
ANTENNA RADAR METEO	ANT-312	622-2501-001	COLLINS
ANTENNA RADAR METEO	ANT-318	622-2504-001	COLLINS
RICEVITORE VOR/ ILS/MB	VIR-31A	622-1239-XXX	COLLINS
RICEVITORE VOR/ ILS/MB	VIR-31H	622-2819-XXX	COLLINS
RICETRASMETTITORE D.M.E.	DME-42	622-6263-001/3	COLLINS
SERVOMOUNT	351B-3	522-1226-000	COLLINS
SERVOMOUNT	351B-3A	522-2228-000	COLLINS
SERVOMOUNT	351B-3B	522-3389-000	COLLINS
SERVOMOUNT	351B-3C	522-3390-000	COLLINS
SERVOMOUNT	351B-3E	772-5027-001	COLLINS
RICETRASMETTITORE RADAR METEO	WXT-200A	622-4021-001	COLLINS
RICETRASMETTITORE RADAR METEO	WXT-250A	622-4022-001	COLLINS
INDICATORE RADAR METEO	IND-220	622-5940-001	COLLINS
INDICATORE RADAR METEO	IND-270	622-5941-001	COLLINS
RICETRASMETTITORE VHF	VHF-20A	622-1879-001/2	COLLINS
RICETRASMETTITORE VHF	VHF-20B	622-1334-001/2	COLLINS
SELETTORE MODI AUTOPILOTA	614E-42	622-1523-001/2	COLLINS
BASIC AUTOPILOT COMPUTER	562C-13	622-1522-001/2	COLLINS
PITCH/TURN CONTROL	614E-41	622-1210-001/2	COLLINS
PITCH/TURN CONTROL	614E-41A	622-3246-001/2	COLLINS
ANNUNCIATOR UNIT	AP106	629-0053-001	COLLINS
ANNUNCIATOR UNIT	AP107	629-0054-001	COLLINS
RETE LEVEL SENSOR	454N-2	622-2297-001/2	COLLINS
RETE LEVEL SENSOR	454N-2D	622-5375-001/2	COLLINS
TRIM SERVO MONITOR	454N-3	622.2814-001	COLLINS
ANNUNCIATOR ADAPTER	998E-1	622-4217-001	COLLINS
RICEVITORE VOR/ ILS	51RV-1A	522-4366-001	COLLINS
RICEVITORE ECCITATORE HF	671U-4	787-6566-XXX	COLLINS
RICEVITORE ECCITATORE HF	671U-A	787-6934-XXX	COLLINS
RICEVITORE ECCITATORE HF	671U-4AN	622-2631-XXX	COLLINS
RICEVITORE ECCITATORE HF	671U-4B	792-6316-XXX	COLLINS

RICEVITORE ECCITATORE HF	671U-4D	622-1342-XXX	COLLINS
RICEVITORE ECCITATORE HF	671U-4E	622-2620-XXX	COLLINS
HORIZONTAL SITUATION INDICATOR	AQU-2/A	100524	ASTRONAUTICS
TURN SLIP INDICATOR	VS-1	46054	AERITALIA
TURN SLIP INDICATOR	VS-2	47480	AERITALIA
RICETRASMETTITORE RADAR DOPPLER	RTA-12A	2085271-1201/3/6/8	BENDIX
RICETRASMETTITORE RADAR DOPPLER	RTA-12B	2085271-1201/2/4/5/7/9/10	BENDIX
DOPPLER FREQUENCY TRACKER	DRA-12C	2087798-1201/2/3/4/5/6	BENDIX
ANTENNA RADAR DOPPLER	ANA-12E	2087244	BENDIX
ANTENNA RADAR DOPPLER	ANA-12F	2087475-1	BENDIX
ANTENNA RADAR DOPPLER	ANA-12G	2087476-1201/2	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12A	2085272-1201	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12A 1CNX	2085272-1202	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12A-2	2085272-1203	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12A-3	2085272-1204	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12A-4	2085272-1205	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12A-5	2085272-1207	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12B	2087031-1201	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12B-1	2087031-1201	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12B-2	2087031-1202	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12B-3	2087031-1203	BENDIX
CONTROL PANEL RADAR DOPPLER	CNA-12B-4	2087031-1206	BENDIX
ANTENNA RADAR DOPPLER	ANA-12A-1	2087477-1201	BENDIX
ANTENNA RADAR DOPPLER	ANA-12A-2	2087477-1202	BENDIX
ANTENNA RADAR DOPPLER	ANA-12AB-1	2067494-1201	BENDIX
ANTENNA RADAR DOPPLER	ANA-12C-1	2087478-1201	BENDIX
ANTENNA RADAR DOPPLER	ANA-12CB-1	2067510-1201	BENDIX
ATC TRASPONDER	SIT421A	S7261-W4001-A3	ITALTEL
ATC TRASPONDER	SIT421A	S7261-W4001-A2	ITALTEL
PIATTAFORMA INERZIALE	SYP-812	1513123-901	SPERRY
PIATTAFORMA INERZIALE	SYP-820	1512008-903	SPERRY
AUTOMATIC OMNIBIRING SELECTOR		89164S-8A	CONRAC
TANK UNIT		FG232A1	HONEYWELL
HORIZONTAL SITUATION INDICATOR		129400-3	ASTRONAUTICS
HORIZONTAL SITUATION INDICATOR		129400-5	ASTRONAUTICS
HORIZONTAL SITUATION INDICATOR		129400-7	ASTRONAUTICS
QUADRETTO COMANDO VOR/ ILS	313N-2	522-2447-505/515/552/562/574	COLLINS
QUADRETTO COMANDO VOR/ ILS	313N-2D	522-2447-556/557/560/563/564/570/571	COLLINS
QUADRETTO COMANDO VOR/ ILS	313N-4B	522-3614-500/503/506	COLLINS

QUADRETTO COMANDO VOR/ ILS	313N-4D	522-3616-501/502/503/504	COLLINS
QUADRETTO COMANDO VOR/ ILS	313N-5	522-2599-500/502/503/504	COLLINS
QUADRETTO COMANDO VOR/ ILS	313N-5A	522-3617-500/503	COLLINS
COMPRESSOR INLET TEMP.CONTROL		620B2B	LEWIS ENG.
TEMPERATURE CONTROL AMPLIFIER		635E727G2	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		7041M43G01	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		7041M43G02	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G5	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G6	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G7	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G8	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G9	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G10	GENERAL ELECTRIC
TEMPERATURE CONTROL AMPLIFIER		576C358G11	GENERAL ELECTRIC
FUEL QUANTITY INDICATOR		JG130A84	HONEYWELL
FUEL QUANTITY INDICATOR		JG130A87	HONEYWELL
FUEL QUANTITY DUAL INDICATOR		JG310B6	HONEYWELL
INDUCTION COMPASS TRASMITTER	DT-309	620359	SPERRY
COMPENSATOR	CN-1072	620783	SPERRY
INDUCTION COMPASS TRASMITTER	DT-310	1775277	SPERRY
ROLL PITCH DRIVE GYRO CONTROL	K-6	667857	SPERRY
ROLL PITCH DRIVE GYRO CONTROL	K-6	600748	SPERRY
ROLL PITCH DRIVE GYRO CONTROL	K-6	601696-100	SPERRY
ROLL PITCH DRIVE GYRO CONTROL	K-6A	601696-106	SPERRY
SERVO DRIVE		669778-161	SPERRY
SERVO DRUM		669805	SPERRY
TRIM TAB SERVO MOTOR		669388-01	SPERRY
TRIM TAB SERVO SPROCKET		669352	SPERRY
PILOT CLOCHE CONTROL	B-3	661207	SPERRY
COPILOT CLOCHE CONTROL	B-4	661208	SPERRY
FLIGHT CONTROLLER	A-6	656536-111/211/411	SPERRY
FLIGHT CONTROLLER	A-6	670724	SPERRY
ELECTRONIC CONTROL AMPLIFIER	MB-4	604390B	SPERRY
FLIGHT DIRECTION INDICATOR	ID-864/A	S6146-61072-1	HONEYWELL
CASSETTE TAPE RECORDER	V-1000AB-F		TEAC
CONTROL PANEL TACAN	G-3828	G-3828A/B/M	SIERRA/KING
CONTROL PANEL TACAN	SCU 7124		SIERRA/KING
CONTROL PANEL TACAN	SCU 7215		SIERRA/KING
JUNCTION BOX	E190	2219A/B/C/D	ECKO

Vari G222	G222TCM1	Strumenteria Console Centrale	AERITALIA
Vari G222	G222TCM1	Strumenteria Console Sinistra	AERITALIA
Vari G222	G222TCM1	Strumenteria Pannello Destro	AERITALIA
Vari G222	G222TCM1	Strumenteria Cruscotto Destro	AERITALIA
Vari G222	G222TCM1	Strumenteria Cruscotto Centrale	AERITALIA
Vari G222	G222TCM1	Strumenteria Pannello Cruscotto Centrale	AERITALIA
BUSSOLA MAGNETICA	MS17983-2	8.056.000/3	KOLLSMAN
BUSSOLA MAGNETICA	AN5766-T3	8.057.000	KOLLSMAN
BUSSOLA MAGNETICA		8.079.005	KOLLSMAN
BUSSOLA MAGNETICA		8.080.003	KOLLSMAN
BUSSOLA MAGNETICA		8.135.004	KOLLSMAN
RICEVITORE DI NAVIGAZIONE	ANV 141	145-0246/XX	MARCONI
AMPLIFIER POWER SUPPLY	AM-4606/ASN75	2590371	SPERRY
ELECT MAGNETIC COMPASS COMPENSATOR	CN-1142/ASN75	2590497	SPERRY
COMPASS SET CONTROL	C-8021/ASN75	2589386 /-902	SPERRY
RICETRASMETTITORE RADAR METEO	E290	M3051B	ECKO
RICETRASMETTITORE RADAR METEO	E290	M3066A	ECKO
INDICATORE RADAR METEO	E290	M6300	ECKO
ANTENNA RADAR METEO	E290	M2269	ECKO
JUNCTION BOX	E290	M3090A	ECKO
QUADRETTO COMANDO AUTOPILOTA	614E-5A	792-6348-001/2/3/4	COLLINS
INDICATORE ACCELEROMETRO		8.029.000	KOLLSMAN
INDICATORE ACCELEROMETRO		8.029.003	KOLLSMAN
INDICATORE ACCELEROMETRO		8.029.051	KOLLSMAN
VIROSBANDOMETRO	MD1	A1050	KOLLSMAN
FUEL QUANTITY INDICATOR		393084-16648	SIMMONDS
FUEL QUANTITY INDICATOR		393084-024	SIMMONDS
FUEL QUANTITY INDICATOR		393084-025	SIMMONDS
FUEL QUANTITY INDICATOR		393084-026	SIMMONDS
INDICATORE RADAR ALTIMETRO		JG206B5B	HONEYWELL
RICETRASMETTITORE RADAR ALTIMETRO		HG7105A6	HONEYWELL
INDICATORE RADAR ALTIMETRO		JG206B3	HONEYWELL
RICETRASMETTITORE RADAR ALTIMETRO	MW17	17MW1001-1	AERITALIA
SCHEDA ARINC 552 INTERFACE		17MW1016	AERITALIA
SCHEDA AUTOPILOT SPERRY		17MW1015	AERITALIA
HELICOPTER CRASH POSITION INDICATOR SYSTEM CPL-2000		CPL-2000	SPAR
VHF TRANSCEIVER	807A	97607-100/101/103	
VHF MARINE TRANSCEIVER CONTROL		C-722A	WULFSBERG
VHF MARINE TRANSCEIVER CONTROL		C-962A	WULFSBERG

MARKER BEACON RECEIVER	51Z-3		COLLINS
ANTENNA VHF/FM	437S-1	522.4773-001	COLLINS
ANTENNA VHF/FM	437S-1A	772-5298-001	COLLINS
ANTENNA VHF/FM	437S-1B	777-1265-001	COLLINS
ANTENNA VHF/FM	437S-1G	622-2169-001/002	COLLINS
RICETRASMETTITORE VHF/FM	ART 132	145-0118/01-04	MARCONI
PROPELLER		63E60-27	HAMILTON STD
RICETRASMETTITORE RADAR METEO	RT-1301B	4000966-0103/0106	BENDIX
ANTENNA DRIVE	DA1203A	4000504-0302/0303	BENDIX
ANTENNA RADAR ARRAY	AA-1212A	4000525-1212	BENDIX
ANTENNA RADAR ARRAY	AA-1215A	4000525-1215	BENDIX
ANTENNA RADAR ARRAY	AA-1218A	4000525-1218	BENDIX
ANTENNA DRIVE	DA-144A	4000790-4401/4402/4403/4404/4405/4406	BENDIX
ANTENNA RADAR ARRAY	AA-1210A	4000525-1210	BENDIX
PARABOLIC RADAR ANTENNA	AT-143A	4000654-4301/4302/4303/4304/4305/4306/4307/4308	BENDIX
PARABOLIC RADAR ANTENNA	AT-133A	4000765-3301/3302	BENDIX
TRIM TAB SERVO	334D-2-33	522-1356-00	COLLINS
TRIM TAB SERVO	334D-2-33A	522-2374-00	COLLINS
TRIM TAB SERVO	334D-2-33B	522-2385-00	COLLINS
TRIM TAB SERVO	334D-2-33C	522-2365-00	COLLINS
TRIM TAB SERVO	334D-2-33D	522-3466-00	COLLINS
TRIM TAB SERVO	334D-2-33E	522-3505-00	COLLINS
TRIM TAB SERVO	334D-2-33F	522-4865-001	COLLINS
INDICATORE FDI	329B-8G	777-1224-001	COLLINS
RICETRASMETTITORE UHF	AN/ARC-164(V) 12/16	RT-1288	RAYTHEON
RICETRASMETTITORE UHF	AN/ARC-164(V) 12/16	RT-1288A	RAYTHEON
RADIO CONTROL SET	AN/ARC-164(V) 12/16	C-10547	RAYTHEON
OXIGEN REGULATOR	MD-2	14800-5	ARO/CARLETON
OXIGEN REGULATOR	CRU-44/A	14800-8	ARO/CARLETON
OXIGEN REGULATOR	CRU-21/A	14950-7	ARO/CARLETON
OXIGEN REGULATOR	CRU-34/A	14950-12	ARO/CARLETON
OXIGEN REGULATOR	CRU-47/A	14950-47	ARO/CARLETON
OXIGEN REGULATOR	CRU-49/A	14950-22	ARO/CARLETON
OXIGEN REGULATOR	CRU-48/A	14950-23	ARO/CARLETON
OXIGEN REGULATOR	CRU-52/A	14950-26	ARO/CARLETON
OXIGEN REGULATOR	CRU-73/A	14950-34M 2894-10AB2	ARO/CARLETON
OXIGEN REGULATOR	CRU-68/A	14950-34	ARO/CARLETON
ADF CONTROL UNIT	614L-8	522-2357-000/011/019/021/022/024/026/028/031/032/035/036/037/039	COLLINS
SELETTORE MODI AUTOPILOTA	614E-20R	622-0944-006/007	COLLINS

SELETTORE MODI AUTOPILOTA	614E-20S	622-5486-001/011	COLLINS
SELETTORE MODI AUTOPILOTA AUX	614E-37	622-0950-001/002	COLLINS
AIR DATA CONTROL	590A-3H	792-6672-001/002/004/005/008/019	COLLINS
AIR DATA CONTROL	590A-3J	622-1001-001/002/019	COLLINS
AIR DATA CONTROL	590A-3K	622-3204-001/042	COLLINS
SERVO MOTORE	334C-6	777-1061-001	COLLINS
SERVO MOTORE	334C-6A	792-6780-001	COLLINS
SERVO MOTORE	334C-6C	792-6972-001	COLLINS
SERVOMOUNT	351B-6	777-1062-001	COLLINS
SERVOMOUNT	351B-6A	792-6784-001	COLLINS
SERVOMOUNT	351B-6B	792-6785-001	COLLINS
SERVOMOUNT	351B-6C	792-6973-001	COLLINS
SERVOMOUNT	351B-6E	622-5229-001/002	COLLINS
SERVOMOUNT	351B-6F	622-5150-001/002	COLLINS
SERVOMOUNT	351B-6G	622-5151-001/002	COLLINS
SERVOMOUNT	351B-6H	622-5152-001/002	COLLINS
SERVOMOUNT	351B-6J	622-6155-001	COLLINS
SERVOMOUNT	351B-6K	622-6156-001	COLLINS
SERVOMOUNT	351B-6L	622-6157-001	COLLINS
SERVOMOUNT	351B-6M	622-6158-001	COLLINS
SERVOMOUNT	351B-7	777-1557-001	COLLINS
SERVOMOUNT	351B-7A	792-6782-001	COLLINS
SERVOMOUNT	351B-7B	792-6783-001	COLLINS
SERVOMOUNT	351B-7C	792-6974-001	COLLINS
SERVOMOUNT	351B-8	792-6975-001	COLLINS
COURSE INDICATOR	331A-6A	522-2782-004/014/024/034/037	COLLINS
COURSE INDICATOR	331A-6A1	522-4279-001/003	COLLINS
COURSE INDICATOR	331A-6K	552-3875-001	COLLINS
COURSE INDICATOR	331A-6K1	777-1258-001	COLLINS
AMPLIFICATORE AUTOPILOTA	562C-5B	622-1116-018/019/004	COLLINS
AMPLIFICATORE AUTOPILOTA	562C-5C	622-1281-001/007	COLLINS
AMPLIFICATORE AUTOPILOTA	562C-5F	622-2614-012	COLLINS
TRANSMITTER RATE GYROSCOPE	TRU-2A/A	GG2479AA01	HONEYWELL
REMOTE HEADING AND COURSE SELECTOR	614E-22B	792-6221-001/006/011	COLLINS
REMOTE HEADING AND COURSE SELECTOR	614E-22F	622-1406-001	COLLINS
REMOTE HEADING AND COURSE SELECTOR	614E-22M	622-4924-001	COLLINS
RADIO ALTITUDE INDICATOR	339H-1	522-4114-XXX	COLLINS
RADIO ALTITUDE INDICATOR	339H-1A	522-4354-002	COLLINS
RADIO ALTITUDE INDICATOR	339H-1B	522-4363-XXX	COLLINS

COURSE INDICATOR	331A-3G	522-2638-000/001/002/003/005/006/007/008	COLLINS
COURSE INDICATOR	331A-8G	772-5370-001/002/003/005	COLLINS
RICETRASMETTITORE RADAR METEO	RT-1201A	4000502-0101	BENDIX
RADAR INDICATOR	IN-1202A	4000503-XXXX	BENDIX
RICETRASMETTITORE RADAR METEO	RDR-1E/ED	2067157-XXXX	BENDIX
INDICATORE RADAR ALTIMETRO		8.476.001	GALILEO AVIONICA
MACH AIRSPEED INDICATOR		8.193.006	GALILEO AVIONICA
NAVIGATION DATA ENTRY		02EF1001-2	GALILEO AVIONICA
NAVIGATION DATA ENTRY		16EF1001-1/2	GALILEO AVIONICA
NAVIGATION DATA ENTRY		21EF1001-1	GALILEO AVIONICA
RICETRASMETTITORE RADAR ALTIMETRO	MW19	19MW1001-1/2	GALILEO AVIONICA
SELECTOR MODE NAV-WARS		8.353.001	GALILEO AVIONICA
SELECTOR MODE NAV-WARS		8.353.010	GALILEO AVIONICA
NAVIGATION FIXING SELECTOR		8.352.001	GALILEO AVIONICA
FLIGHT CONTROL COMPUTER		27CT1001-4	GALILEO AVIONICA
FLIGHT CONTROL COMPUTER		27CT1001-6	GALILEO AVIONICA
DOPPLER VELOCITY SENSOR DVS	ANV-353	195-1341/06	MARCONI
ADF CONTROL UNIT	614L-12	787-6366-XXX	COLLINS
ADF CONTROL UNIT	614L-13	792-6275-XXX	COLLINS
RICEVITORE	ADF-60B	622-2873-001	COLLINS
ANTENNA ADF	ANT-60A	622-2363-001/002	COLLINS
ANTENNA ADF	ANT-60B	622-3710-001	COLLINS
RICEVITORE	ADF-60A	622-2362-001	COLLINS
ADF CONTROL PANEL	614L-11	777-1493-XXX	COLLINS
ELABORATORE DATI ARIA	590A-3J1	622-4393-001	COLLINS
ELABORATORE DATI ARIA	590A-3K1	622-4394-001	COLLINS
SERVOMOTORE	334C-6B	792-6781-001	COLLINS
INDICATORE ADI	ADI-55V = (329B-8Y)	622-3374-002	COLLINS
DIRECTION FINDER	DF-301E	622-0902-005	COLLINS
VALVOLA DI FLUSSO	C2	664543C-3	SPERRY
GIROSCOPIO DIREZIONALE		8.071.001	AERITALIA
REMOTE COMPENSATOR	CS-313	2586257-1	SPERRY
DIGITAL COMPASS CONTROLLER	CC-161	2586261-1	SPERRY
DIRECTIONAL GYRO	C-12	2586333-1/2/3	SPERRY
AMPLIFIER POWER SUPPLY	SL-120	2589226-1	SPERRY
FLUX VALVE	FX-270	1775277	SPERRY
AMPLIFIER POWER SUPPLY	SL-120	2586384-1	SPERRY
AMPLIFIER POWER SUPPLY	SL-120	2589226-1BC	SPERRY
RICEVITORE VOR/ ILS	51RV-1	522-2450-XXX	COLLINS

ANTENNA VOR/LOC	NA15-3A	DMN4-15	DORNE MARGOLIN
RICETRASMETTITORE RADAR ALTIMETRO	860F-4	522-3890-XXX	COLLINS
RADIO ALTITUDE INDICATOR	339H-1C	522-4504-001	COLLINS
RADIO ALTITUDE INDICATOR	339H-1D	522-4525-001	COLLINS
RADIO ALTITUDE INDICATOR	339H-2	522-4825-001	COLLINS
INDICATORE TRIM	327D-1W	458-0405-000	COLLINS
INDICATORE HSI	HSI-45 = (331A-9G)	622-4298-001	COLLINS
INDICATORE R.M.I.	332C-4	482-0061-000	COLLINS
RICETRASMETTITORE RADAR METEO	RT-1401B	4000831-0103/105/106	BENDIX
RADAR COLOR INDICATOR	IN-2025B	4001670-2511	BENDIX
ANTENNA RADAR ARRAY	AA-1218A	4000525-1218	BENDIX
ATC TRASPONDER	TDR-90	622-1270-001	COLLINS
FUEL QUANTITY INDICATOR		710-371-1	INTERTENIQUE
INVERTER STATICO		PC-16	
INDICATORE CONTAGIRI APU		E242BD	OFFICINE GALILEO
SHUTOFF BUTTERFLY VALVE		321916-1-1	NORMALAIR GARRETT LTD
AIRFLOW SHUTOFF REGULATOR		396300-1-1	NORMALAIR GARRETT LTD
AIR FLOW REGULATOR		3353B000	NORMALAIR GARRETT LTD
ELECTRO MECHANICAL ACTUATOR		PT220100	SARMA
AIR TURBINE ENGINE STARTER		383904-1-1	ALLIED SIGNAL
REGULATING & RELIEF VALVES		38E85-2B	BENDIX
VALVE, SOLENOID		319980-7-1	NORMALAIR GARRETT LTD
CABLE TENSION ADJUSTE(REGULATOR)		178486	
RADAR INDICATOR	PPI-1TB	2070964-0104/0105	BENDIX
RICETRASMETTITORE RADAR METEO	RTA-1FB	2070963-0101/0102/103	BENDIX
MOUTING BASE	MBA-IGB	2041441-0101/0102	BENDIX
RICETRASMETTITORE RADAR METEO	RDR-1F	2070410-XXXX	BENDIX
RADAR INDICATOR	PPI-1L	2070411-XXXX	BENDIX
RADAR INDICATOR	PPI-1N	2070943-XXXX	BENDIX
RADAR COLOR INDICATOR	PPI-1T	2041232-0101	BENDIX
RADAR ANTENNA	ANT-1T	2070409-XXXX	BENDIX
RADAR CONTROL UNIT	CON-1S	2070552-XXXX	BENDIX
RADAR CONTROL UNIT	CON-1R	2070412-XXXX	BENDIX
RADAR ANTENNA	ANT-1TB	2041440-XXXX	BENDIX
RADAR CONTROL UNIT	CON-1SB	2070965-0101/0102	BENDIX
RADAR CONTROL UNIT	CON-1FB	2041287-0101	BENDIX
RADAR CONTROL UNIT	CON-1RB	2070966-0101	BENDIX
ANTENNA AZINUT CONTROL	CON-1TB	3614657-0101	BENDIX
RICETRASMETTITORE D.M.E.	DME-40	622-1233-001	COLLINS

ATC TRASPONDER	621A-3	522-2703-000/011/012/013	COLLINS
ATC TRASPONDER	621A-6A	622-2224-001/002/003/101/102	COLLINS
ATC TRASPONDER	621A-6	787-6211-001/002/003	COLLINS
RICETRASMETTITORE VHF/AM	618M-3A	622-1396-XXX	COLLINS
RICETRASMETTITORE VHF/AM	618M-3	622-1181-XXX	COLLINS
ANTENNA VHF-FM	437S-1C	777-1950-001/003	COLLINS
RADAR INDICATOR	PPI-1E-2	2085268-XXXX	BENDIX
RADAR INDICATOR	PPI-1GT	2070110-0501	BENDIX
QUADRETTO COMANDO VOR/ ILS	313N-3/3D	522-2448-XXX	COLLINS
D.M.E. DISTANCE INDICATOR	339D-1	522-1859-XXX	COLLINS
D.M.E. DISTANCE INDICATOR	339D-1A	522-2604-XXX	COLLINS
D.M.E. DISTANCE INDICATOR	339D-3B	522-2919-XXX	COLLINS
D.M.E. DISTANCE INDICATOR	339D-3C	522-2920-003	COLLINS
D.M.E. DISTANCE INDICATOR	339D-3D	522-3343-XXX	COLLINS
AIRCRAFT PASSANGER ADDRESS AMPLIFIER	346D-1	522-0875-006	COLLINS
RICETRASMETTITORE D.M.E.	860E-2	522-2702-XXX	COLLINS
RICETRASMETTITORE VHF/AM	618M-1	522-2466-004	COLLINS
RICETRASMETTITORE VHF/AM	618M-A	522-2754-004	COLLINS
RICETRASMETTITORE VHF/AM	618M-B	522-2755-004	COLLINS
RICETRASMETTITORE VHF/AM	618M-C	522-2756-004	COLLINS
RICETRASMETTITORE VHF/AM	618M-D	522-3232-004	COLLINS
SERVO DRIVE ASSEMBLY		669777-541	SPERRY
SERVO DRUM E BRACKET ASSEMBLY		669779	SPERRY
ACCELEROMETER ASSEMBLIES	MA-1	2119-001-1/2/3	BURTON
ACCELEROMETER ASSEMBLIES	MA-1	2119-500	BURTON
AIRCRAFT CLOCK	A-13A	W-33-7545-10	WARKMANN
ANTI ICING TEMPERATURE INDICATOR		EKCC-18043	WACLIN INC.
INERTIAL NAVIGATION UNIT (INU)	LTN72R	454620-01-40-62	LITTON
MODE SELECTOR UNIT (MSU)	LTN72R	452100-02	LITTON
CONTROL DISPLAY UNIT (CDU)	LTN72R	454640-01-08	LITTON
ATTITUDE INDICATOR		6745	LOUIS NEWMARK
ATTITUDE INDICATOR		6746	LOUIS NEWMARK
RICETRASMETTITORE D.M.E.	860E-3	522-4229-001/002	COLLINS
CABIN PRESSURE INDICATOR		AF200	AEROSONIC
CABIN PRESSURE INDICATOR		AF200A	AEROSONIC
RICETRASMETTITORE HF	718U-5	622-0591-XXX	COLLINS
RICETRASMETTITORE HF	718U-5N	622-2895-XXX	COLLINS
RICETRASMETTITORE HF	718U-5M	622-3347-001/002	COLLINS
RICETRASMETTITORE D.M.E.	AVQ-85	MI-585015-1/2	RCA

D.M.E. DISTANCE INDICATOR	AVQ-85	MI-585016-1/2	RCA
ANTENNA D.M.E.	AVQ-85	MI-591089-1	RCA
DISTANCE INDICATOR/GROUND SPEED INDIC	AVQ-85	MI-585017-1/2/3/4/5/6/7/8	RCA
DIGITAL TO SYNCRO CONVERTER	AVQ-85	MI-585048	RCA
DC SELSYN POSITION INDICATOR		8DJ49GAW1	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GAX1	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GAY	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GAW2	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GAX2	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GAY2	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GBV2	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GLAL2	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GLAM2	GENERAL ELECTRIC
DC SELSYN POSITION INDICATOR		8DJ49GLAV2	GENERAL ELECTRIC
VOLMETER	AN 3203V30	135244	WESTON
THERMOMETER INDICATOR		162B2	LEWIS ENG.
THERMOMETER INDICATOR		162B3	LEWIS ENG.
THERMOMETER INDICATOR		162B3A	LEWIS ENG.
THERMOMETER INDICATOR		162B4	LEWIS ENG.
ELEVATOR TRIM TAB ADAPTER CONTROL		40002132	SPERRY
AIRCRAFT CLOCK	A-13A	22322-ET-12	WALTHAM PRECISION
AIRCRAFT CLOCK	A-13A	400164	WALTHAM PRECISION
AIRCRAFT CLOCK	A-13A	400095	WALTHAM PRECISION
FUEL QUANTITY INDICATOR		JG412A2	HONEYWELL
FUEL QUANTITY INDICATOR		JG412A3	HONEYWELL
FUEL QUANTITY INDICATOR		JG412A4	HONEYWELL
FUEL QUANTITY INDICATOR		JG412A10	HONEYWELL
FUEL QUANTITY INDICATOR		JG412A1	HONEYWELL
FUEL QUANTITY INDICATOR		JG412A11	HONEYWELL
FUEL QUANTITY INDICATOR		JG412A56	HONEYWELL
FUEL QUANTITY INDICATOR		JG402A2	HONEYWELL
FUEL QUANTITY INDICATOR		JG402A4	HONEYWELL
FUEL QUANTITY INDICATOR		JG402A3	HONEYWELL
FUEL QUANTITY INDICATOR		JG402A32	HONEYWELL
GLIDESLOPE RECEIVER	51V-4	522-2467-XXX	COLLINS
GLIDESLOPE RECEIVER	51V-4A	522-2766-XXX	COLLINS
GLIDESLOPE RECEIVER	51V-4C	522-2766-111/211	COLLINS
HYDRAULIC PRESSURE INDICATOR		18-1105	COURTER PRODUCT
DC SELSYN POSITION INDICATOR	MS28023-1	8DJ48FAL2	GENERAL ELECTRIC

HYDRAULIC PRESSURE INDICATOR	ME-1	AW-2-17-G	AMETEK
HYDRAULIC PRESSURE INDICATOR	ME-1	AW2017AC01	AMETEK
AC LOADMETER INDICATOR	1012	166726	WESTON
INSTRUMENT SWITCHING UNIT		4100	SEABOARD ELECTRONIC
OIL PRESSURE INDICATOR		18-1278	COURTER PRODUCT
OMNIBEARING SELECTOR	336A-3	522-1022-005	COLLINS
OMNIBEARING SELECTOR	336A-3A	522-1023-005	COLLINS
OMNIBEARING SELECTOR	336A-3W	522-2410-005	COLLINS
VOLMETER	AN 3203V30	560-166	HICKOK
VOLMETER	AN 3203V150	560-235	HICKOK
TEMPERATURE INDICATOR	MJ2	152B2	LEWIS ENG.
TEMPERATURE INDICATOR	MJ6	152B3	LEWIS ENG.
TEMPERATURE INDICATOR	MJ1	152B4	LEWIS ENG.
TEMPERATURE INDICATOR	MJ3	152B5	LEWIS ENG.
TEMPERATURE INDICATOR	MJ1	152B44	LEWIS ENG.
QUANTITY INDICATOR		EA100ANH	LIQUIDOMETER
QUANTITY INDICATOR		EA100AN17	LIQUIDOMETER
QUANTITY INDICATOR		EA100AN53	LIQUIDOMETER
QUANTITY INDICATOR		EA100AN62	LIQUIDOMETER
QUANTITY INDICATOR		EA100AN70	LIQUIDOMETER
QUANTITY INDICATOR		EA100AN93	LIQUIDOMETER
QUANTITY INDICATOR		EA100ANH94	LIQUIDOMETER
QUANTITY INDICATOR		EA100ANH97	LIQUIDOMETER
QUANTITY INDICATOR		EA100ANH98	LIQUIDOMETER
QUANTITY INDICATOR		EA100ANH126	LIQUIDOMETER
QUANTITY INDICATOR		EA100ANH133H	LIQUIDOMETER
QUANTITY INDICATOR		EA100ANH144	LIQUIDOMETER
QUANTITY INDICATOR		EA102AN44	LIQUIDOMETER
QUANTITY INDICATOR		EA102AN65	LIQUIDOMETER
QUANTITY INDICATOR		EA102AN116	LIQUIDOMETER
QUANTITY INDICATOR		EA124AN110	LIQUIDOMETER
QUANTITY INDICATOR		EA124AN115	LIQUIDOMETER
QUANTITY INDICATOR		EA148AN47	LIQUIDOMETER
QUANTITY INDICATOR		EA148AN46	LIQUIDOMETER
QUANTITY INDICATOR		EA148AN51	LIQUIDOMETER
QUANTITY INDICATOR		EA148AN71	LIQUIDOMETER
PERISCOPIC SEXTANT		1471B-01B	KOLLSMAN
PERISCOPIC SEXTANT		1471-01	KOLLSMAN
PERISCOPIC SEXTANT		1471B-01	KOLLSMAN

SEXTANT MOUNT		1708-01	KOLLSMAN
SEXTANT MOUNT		7108-01B	KOLLSMAN
SEXTANT MOUNT		A30480 00 003	KOLLSMAN
TEMPERATURE INDICATOR	MS24569-1	9A400	PENN AIRBORNE
TEMPERATURE INDICATOR	EUH-15A/A	9A375	PENN AIRBORNE
TEMPERATURE INDICATOR	MS24560-1	9A550	PENN AIRBORNE
POSITION INDICATOR		8DJ48FAR2	GENERAL ELECTRIC
PRESSURE ALTIMETER		A-80-AAU-8/A	AEROSONIC
PRESSURE ALTIMETER		A80-AAU-8A/A	AEROSONIC
OXIGEN REGULATOR	CRU-69/A	2894-10A-A2B	BENDIX
OXIGEN REGULATOR	CRU-69/A	2894-10A-B2B	BENDIX
OXIGEN REGULATOR	CRU-69/A/A	3260010-0101	BENDIX
OXIGEN REGULATOR	CRU-69/A/A	3260010-0201	BENDIX
OXIGEN REGULATOR		2894-10C-B10	BENDIX
PRESSURE TRASMITTER	F2A	MS28005-2	U.S. GAUGE
PRESSURE TRASMITTER	F3	MS28005-3	U.S. GAUGE
PRESSURE TRASMITTER	F3A	MS28005-4	U.S. GAUGE
RADIO MAGNETIC INDICATOR	RMI-36	622-2506-XXX	COLLINS
D.M.E. BEARING DISTANCE INDICATOR	BDI-36	622-3702-XXX	COLLINS
P.A. CONTROL PANEL		C-1614/AIC13	ANDREA SYSTEMS
P.A. AUDIO AMPLIFIER		AM-944/AIC13	ANDREA SYSTEMS
P.A. CONTROL PANEL		4K11060-101	ANDREA SYSTEMS
P.A. CONTROL PANEL		4K11060-101A	ANDREA SYSTEMS
RICETRASMETTITORE UHF	AN/ARC-164(V)	RT-1168 (705906-802)	MAGNAVOX
RICETRASMETTITORE UHF	AN/ARC-164(V)	RT-1168B	MAGNAVOX
RICETRASMETTITORE UHF	AN/ARC-164(V)	RT-1145	MAGNAVOX
RICETRASMETTITORE UHF	AN/ARC-164(V)	RT-1145B	MAGNAVOX
UHF CONTROL PANEL	AN/ARC-164(V)	C-9533	MAGNAVOX
UHF CONTROL PANEL	AN/ARC-164(V)	C-9680A	MAGNAVOX
UHF CONTROL PANEL	AN/ARC-164(V)	C-9680B	MAGNAVOX
UHF CONTROL PANEL	AN/ARC-164(V)	C-9681	MAGNAVOX
UHF CONTROL PANEL	AN/ARC-164(V)	C-9682	MAGNAVOX
FREQUENCY CHANNEL INDICATOR	AN/ARC-164(V)	ID-1961	MAGNAVOX
FREQUENCY CHANNEL INDICATOR	AN/ARC-164(V)	ID-1961A	MAGNAVOX
ADF POWER SUPPLY	AN/ARC-164(V)	PP-7171	MAGNAVOX
RATE OF CLIMB INDICATOR		RC-60	AEROSONIC
RATE OF CLIMB INDICATOR		RC-60MS	AEROSONIC
RATE OF CLIMB INDICATOR		RC-60MS-10-3	AEROSONIC
RATE SWITCHING GYRO	MC-1	15826-1	PIONEER

RADIO MAGNETIC INDICATOR		ID-250A/ARN	BORG
SERVO TEMPERATURE INDICATOR	EHU-15/A	8DJ100WAA1	GENERAL ELECTRIC
SERVO TEMPERATURE INDICATOR	EHU-15/A	8DJ100WAA2	GENERAL ELECTRIC
SERVO ALTIMETER		WL/1101AM/MS/X	SMITHS INDUSTRIES
SERVO ALTIMETER		WL/1103AM/MS/X	SMITHS INDUSTRIES
SERVO ALTIMETER		WL/1105AM/MS/2	SMITHS INDUSTRIES
SERVO ALTIMETER		WL/1150AM/MS/2	SMITHS INDUSTRIES
RATE SWITCHING GYRO	7650-C	140540-01-01	LEAR SIEGLER
PRESSURE INDICATOR	SR-6A	MS28010-1	U.S. GAUGE
PRESSURE INDICATOR		SRD-7A	U.S. GAUGE
PRESSURE INDICATOR		SRD-7C	U.S. GAUGE
PRESSURE INDICATOR		SRD-4A	U.S. GAUGE
PRESSURE INDICATOR		SRD-4G	U.S. GAUGE
PRESSURE TRASMITTER	ST-7A	MS28005-5	U.S. GAUGE
TACHOMETER INDICATOR	MU-1	8DJ81CAA1	GENERAL ELECTRIC
TACHOMETER INDICATOR	MU-1	8DJ81CAA2	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-5/A	8DJ81LAA1	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-5/A	8DJ81LAA2	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-5/A/A	8DJ81LCA2	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-6/A	8DJ81LWA1	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-6/A	8DJ81LWA2	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-6/A	8DJ81LWA3	GENERAL ELECTRIC
TACHOMETER INDICATOR	ERU-6/A/A	8DJ81LZA2	GENERAL ELECTRIC
TOTALIZER		RG14D3	HONEYWELL
TOTALIZER		RG14D7	HONEYWELL
POSITION TRASMITTER		8TJ39AAT2	GENERAL ELECTRIC
TRUE AIRSPEED INDICATOR	M-1A	724CU-4-012	KOLLSMAN
TRUE AIRSPEED INDICATOR	G-1	724CU-5-03	KOLLSMAN
TRUE AIRSPEED INDICATOR	M-1	724CU-5-011	KOLLSMAN
TRUE AIRSPEED INDICATOR	M-1	724CU-8-011	KOLLSMAN
TRUE AIRSPEED INDICATOR	M1A	724DU-4-012	KOLLSMAN
TRUE AIRSPEED INDICATOR	M1A	724DX-4-012	KOLLSMAN
TRUE AIRSPEED INDICATOR	M1A	E07241 04 003	KOLLSMAN
TURN SLIP INDICATOR	MD-1B	A1605	R.C. ALLEN
TURN SLIP INDICATOR	M3500-05	M3514-09	R.C. ALLEN
VERTICAL VELOCITY INDICATOR		RCS-60-ILW	AEROSONIC
VERTICAL VELOCITY INDICATOR		RCS-60-IL	AEROSONIC
AUDIO CONTROL PANEL	TF-AP-15-A	KR-116-A	T.E.A.M.
AMPLIFIER UNIT	TF-AP-15-A	AM-229-A	T.E.A.M.

AUX AMPLIFIER	TF-AP-15-A	AM-228-A	T.E.A.M.
JUNCTION BOX	TF-AP-15-A	BJ-225-A	T.E.A.M.
TORQUEMETER INDICATOR		698611-1	TEXAS INSTRUMENTS
VHF RECEIVER PLANAR ASSEMBLY	1051A-1	606-3660-002	COLLINS
VHF NAV RECEIVER PLANAR ASSEMBLY	1051A-1	791-8599-XXX	COLLINS
VHF NAV RECEIVER PLANAR ASSEMBLY	1051A-1	797-1480-002	COLLINS
VHF NAV RECEIVER PLANAR ASSEMBLY	1051A-2	777-0062-XXX	COLLINS
VHF NAV RECEIVER PLANAR ASSEMBLY	1051A-2	606-3624-001	COLLINS
VHF NAV RECEIVER PLANAR ASSEMBLY	1051B-1	772-0790-XXX	COLLINS
RADIO MAGNETIC INDICATOR		2105-2105L	AERONETICS
RADIO MAGNETIC INDICATOR		2107-2107L	AERONETICS
RADIO MAGNETIC INDICATOR		2108-2108L	AERONETICS
RADIO MAGNETIC INDICATOR		2109-2109L	AERONETICS
THERMOMETER INDICATOR		147B7	LEWIS ENG.
THERMOMETER INDICATOR		147B7A	LEWIS ENG.
THERMOMETER INDICATOR		147B7B	LEWIS ENG.
ATTITUDE AND HEADING REFERENCE SYSTEM	LCR-100	1455130-XXX	NORTHROP GRUMMAN
TOILET TIMER SWITCH		TD1514-1002	LEACH
TOILET TIMER SWITCH		TD1535-1002	LEACH
TOILET TIMER SWITCH		TD1715-1002	LEACH
TOILET TIMER SWITCH		TD1702-1002	LEACH
INDICATORE RADAR ALTIMETRO	KNI 416	066-3044-XX	HONEYWELL
SENSITIVE ALTIMETER		671CPX4-037	KOLLSMAN
SENSITIVE ALTIMETER		671CPX4-037D	KOLLSMAN
SENSITIVE ALTIMETER		671CPX4-037DF	KOLLSMAN
SENSITIVE ALTIMETER		671CPU19-015	KOLLSMAN
SENSITIVE ALTIMETER		671CPU19-015D	KOLLSMAN
SENSITIVE ALTIMETER		671CPU19-015DF	KOLLSMAN
SENSITIVE ALTIMETER		671CLU4-035	KOLLSMAN
SENSITIVE ALTIMETER		671CLU4-035D	KOLLSMAN
SENSITIVE ALTIMETER		671CLU4-035DF	KOLLSMAN
SENSITIVE ALTIMETER		1845X4-03	KOLLSMAN
SENSITIVE ALTIMETER		1845X4-03D	KOLLSMAN
SENSITIVE ALTIMETER		1845X4-03DF	
BATTERY	L7N72R	500012-01/02	LITTON
BATTERY	L7N72R	500040-03	LITTON
BATTERY	L7N72R	510014-01	LITTON
BATTERY	L7N72R	510018-01	LITTON
ACCELEROMETER		2094-XXX	QED INC.
AUDIO INTERCOMUNICATION UNIT	JZ12	12JZ1001-1	AERITALIA

SCATOLA INTERCONNESSIONE	JZ25	25JZ1001-1	AERITALIA
RICETRASMETTITORE UHF/AM	AN/ARC-159(V)	622-1365-001 (RT-1150)	COLLINS
ANGLE OF ATTACK TRASDUCER		19689-40	TELEDYNE
GYROCOMPASS SYSTEM	C-12	2586333-1/2/3 + COMPLESSIVO DEL SISTEMA	SPERRY
ANGLE OF ATTACK TRASDUCER		19689-30	TELEDYNE
ANGLE OF ATTACK TRASDUCER		800987-17A	TELEDYNE
ANGLE OF ATTACK TRASDUCER	TV-2023	815572	TELEDYNE
SYNCRO AMPLIFIER	AM 6015/A	2592789-902	SPERRY
FUEL FLOW INDICATOR		MAL4901	KEARLEY
FLAP POSITION INDICATOR		114074-2	KRATOS
AIR BRAKE POSITION INDICATOR		114075-1	KRATOS
ATTITUDE DIRECTOR INDICATOR		102379	ASTRONAUTICS
ATTITUDE DIRECTOR INDICATOR		ARU2BA	ASTRONAUTICS
INDICATORE HSI		126610	ASTRONAUTICS
INDICATORE HSI		AQU-6A/A	ASTRONAUTICS
ATTITUDE INDICATOR		501-1646-02	L3 COMMUNICATION
PRESSURE TRASMITTER		MS28131-8T	HONEYWELL
MANIFOLD PRESURE FLOW FUEL INDICATOR		94292305-01	MOOG
OXIGEN PRESSURE TRASMITTER		50724-1	KRATOS
INDICATORE TEMPERATURA GETTO		124T1385	KRATOS
INDICATORE TEMPERATURA GETTO		71701-34A	LEWIS ENG.
FATICOMETRO		M1947	MEGGIT
ALTIMETRO CABINA		8.190.003	AERITALIA
VARIOMETRO		8.191.003	AERITALIA
INDICATORE MACH-ANEMOMETRO		8.193.003	AERITALIA